

## 180 x 90 Degree Door-Spring Assist Instructions

1. Insert threaded shaft into lower hinge pin until jamb nut is bottomed out.
2. Slide washer and spring over the hinge adapter shaft.
3. Thread adjustment washer and tighten until desired closing action is obtained.

Note: Over tightening will cause the spring to bottom out,  
limiting the swing of the door to less than 180 degrees.

4. Thread nut below adjustment washer to prevent slippage.

